Two Tone Test

What it means – The two plots below compare gain linearity for the new Orbital design with competitor designs. Two tones at 20.200000 GHz and 20.200100 GHz are injected into the LNBs to provide 0 dBm out. The first spur in the Orbital design is over -40 dBc down compared to the multiple spurs on the competitive LNB starting at only -10 dB down. Intermodulation (IM) distortion for a given output is reduced in the Orbital LNB while providing higher overall gain (60 dB minimum for the Orbital LNB, versus 55 dB for the competitor LNB).





Orbital LNB



How it works – The LNB has to amplify the multiple signals from the satellite by a factor of a million (60 dB) without adding significant noise (noise figure), but also to perform this conversion <u>without</u> <u>adding distortion</u>. The above graphs represent the comparative levels of distortion between the Orbital design and competitive designs. Basically, if you put two signals into the LNB, you should get two signals, and only two signals, out. You can imagine the mess using a poor quality LNB when you amplify and convert the dozens or even hundreds of signals from the satellite.

What it shows – While an LNB would never be operated at 0 dBm output level, the test and design represent the linear conversion quality of each LNB and the P1 dB compression point. The Two Tone tests are proxies for the quality of conversion that is absolutely necessary for low bit error rate satellite transmissions. LNB non-linearity starts at much lower levels than 0 dBm output, and the 2 tone test is the best method of comparing the quality of design and manufacture of LNBs. The ultimate benefit to the end user is lower noise figure, higher conversion gain, and most importantly, lower bit error rate for their digital transmissions.

Orbital Ka Isolator

Until recently, Orbital has been adding an input isolator to the LNB when required by the customer. Because of recent proprietary improvements in isolator design, Orbital has been able to reduce the width of the isolator so that it can fit inside the case of a standard LNB (without the load sticking out sideways). This gives the added benefit of sealing the isolator into the case with the LNB.